



# BNC ADAPTORS

Bulkhead Feed Thru  
Isolated (UG-492D/U)

**BNC-3191**



Bulkhead Feed Thru  
(UG-492D/U)

**BNC-3192**  
**BNC-3192-75**  
**BNC-7192**



Bulkhead Feed Thru  
Isolated (UG-492D/U)

**BNC-3193**  
**BNC-3193-75**



Jack-Plug-Jack UG-274B/U, F-M-F

**BNC-3374**  
**BNC-3374-75**  
**BNC-3874**  
**BNC-7374**

**BNC-3374-BULK (100/Pack)**




Jack-Jack-Jack  
Adaptor F-F-F

**BNC-3375**




P.C.B Mount, 90° & 180°  
Low & High Profile



**BNC-3879L** Right Angle Low Profile  
H:15.6mm (Reference)

**BNC-3879H** Right Angle High Profile  
H:13.1mm (Reference)

**BNC-3878** 180° Low Profile



BNC M-F Right Angle  
UG-306A/U, M-F

**BNC-3306**  
**BNC-3306-75**



Plug-Plug  
UG-491/U, M-M

**BNC-3391**



Plug-Plug-Plug  
Adaptor, M-M-M

**BNC-7376**



Plug-Jack-Jack  
"F Adaptor"

**BNC-7368**



Jack-Jack  
UG-914/U, F-F

**BNC-3314**  
**BNC-3314-75**  
**BNC-7314**

**BNC-3314-BULK (100/Pack)**



	Right Angle	T-Type			Y-Type	F-Type
		F-M-F	F-F-F	M-M-M	F-M-F	M-F-F
BNC	BNC-3306(M-F) BNC-3306-75	BNC-3374 BNC-3874 BNC-7374 BNC-3374-75	BNC-3375	BNC-7376	BNC-7366(180) BNC-7367(90)	BNC-7368



Jack-Plug-Jack  
"Y" Adaptor, 180°

**BNC-7366**


**RCA-6001**



RCA-Plug,  
Molding Type,  
Machine Pin

Jack-Jack, Bulkhead Feed-Thru

**RCA-6192**  
**RCA-6192GBK**  
**RCA-6192GRD**  
**RCA-6192GWH**  
**RCA-6192GYW**



Also, See Pg. 60

Jack-Plug-Jack  
"Y" Adaptor 90°

**BNC-7367**

